

MODEL # SP-0X & SP-00X SERIES POWER PACKS OPERATING & MAINTENANCE INSTRUCTIONS

- Maximum air pressure 100 psi. For longest tool life it is recommended to operate at the lowest possible pressure to do the job.
- Tools must be lubricated; either an on-line oiler located no more than 6 ft. from the tool or oil directly through rear of power pack with several drops of pneumatic oil weekly or as needed.
- > Do not exceed recommended wire sizes for jaw
- > Jaws should be cleaned and foreign material removed weekly, more often as necessary.
- Tools can be made either "right hand" or "left hand" by reversing the jaw in housing. When jaws are in place, pivot screw should be "snug" against steel insert. DO NOT OVERTIGHTEN.
- > If tool is used in production line, check pivot screw for tightness daily.

TO RESHARPEN JAWS, RETURN TO CPS.