



Installing Powerflor Railing  
(Ramp has been positioned  
before railing is installed)  
Step #1: Position Railing

Powerflor railing install

Step 2:

Drill 3/8" hole x 6" deep while the railing is in place.

Evacuate concrete dust with shop vac.

With nut installed as shown, drive the concrete anchor into the hole leaving about 1/2" of exposed threads to tighten nut.



Powerflor railing install  
Step 3:  
Using socket & ratchet, tighten  
concrete anchor(s) to secure  
the railing to the subfloor

A close-up photograph of a black, textured metal railing component. A circular hole in the center of the component contains a silver-colored nut. The railing is positioned over a light-colored concrete surface. The text 'Powerflor Railin Install Step 4:' is overlaid on the right side of the image.

Powerflor Railin Install  
Step 4:

Tighten nut on concrete  
anchor until railing is  
secure.