

SR-100 UNIVERSAL SNAP RING TOOL – PNEUMATIC



The SR-100 **Internal** Snap Ring Tool is designed to work with snap rings ranging from $\frac{1}{4}$ " – 6" diameter. A range of tip sizes and angles are available. Tips are ordered separately.

External snap ring tools are available on a custom order basis only.

Tip Spacing Adjustment: To adjust the tip spacing, remove the Allen head screw on the back end of the power pack with a 1/8" Allen Screwdriver. Then, with a 3/32" Allen head screwdriver, remove the small set screw down inside. Now you can access the adjustment screw (3/32") to set the tip spacing. Clockwise to close the jaw tip spacing, or counter-clockwise open the jaw tip spacing. Maximum open spacing is 1.5". Maximum close tip spacing is .125"



Tool Specifications.

Tip Sizes:

Tip Angles:

Tool Length: 11" (with tips)
Tool Length: 10" (without tips)

Tool Weight: 1.75 lbs.

Tool Weight: 1.75 lbs. Tool Diameter: 1.5"

.093, .109" & .120"

Straight, 45-deg, 90-deg